













**Shower Wall Selection**
**1 Find your shower pan size.**

Choose from the list below. Then follow the chart across to find the elements that are right for your custom Swanstone shower. See below for information about Shower Kits.

**2 Choose your shower wall panel height.**

Choose only wall panels directly to the right of your shower pan.

*Note: Actual shower dimensions may vary, some trimming of panels may be required.*

|   |   | 72" high wall panels   | 96" high wall panels   |
|---|---|--|--|
|    | SS-3232 Single Threshold<br>32" D x 32" W             | SK-363672<br>STMK72-3636<br>SQMK72-3636<br>CCSK72-3636             | SK-363696<br>STMK96-3636<br>SQMK96-3636<br>CCSK96-3636             |
|    | SS-3248 Single Threshold<br>32" D x 48" W             | SK-364872<br>STMK72-3662<br>SQMK72-3662<br>CCSK72-3648             | SK-364896<br>STMK96-3662<br>SQMK96-3662<br>CCSK96-3648             |
|    | SS-3260 Single Threshold<br>32" D x 60" W             | SK-366072<br>STMK72-3662<br>SQMK72-3662<br>CCSK72-3648 + CCSO-1272 | SK-366296<br>STMK96-3662<br>SQMK96-3662<br>CCSK96-3648 + CCSO-1296 |
|   | SR-3260L/R Retrofit Single Threshold<br>32" D x 60" W | SK-366072<br>STMK72-3662<br>SQMK72-3662<br>CCSK72-3648 + CCSO-1272 | SK-366296<br>STMK96-3662<br>SQMK96-3662<br>CCSK96-3648 + CCSO-1296 |
|  | SS-3442 Single Threshold<br>34" D x 42" W             | SK-364872<br>STMK72-3662<br>SQMK72-3662<br>CCSK72-3648             | SK-364896<br>STMK96-3662<br>SQMK96-3662<br>CCSK96-3648             |
|  | SS-3448 Single Threshold<br>34" D x 48" W             | SK-364872<br>STMK72-3662<br>SQMK72-3662<br>CCSK72-3648             | SK-364896<br>STMK96-3662<br>SQMK96-3662<br>CCSK96-3648             |
|  | SS-3454 Single Threshold<br>34" D x 54" W             | SK-366072<br>STMK72-3662<br>SQMK72-3662                            | SK-366296<br>STMK96-3662<br>SQMK96-3662                            |
|  | SS-3460 Single Threshold<br>34" D x 60" W             | SK-366072<br>STMK72-3662<br>SQMK72-3662<br>CCSK72-3648 + CCSO-1272 | SK-366296<br>STMK96-3662<br>SQMK96-3662<br>CCSK96-3648 + CCSO-1296 |
|  | SS-3636 Single Threshold<br>36" D x 36" W             | SK-363672<br>STMK72-3636<br>SQMK72-3636<br>CCSK72-3636             | SK-363696<br>STMK96-3636<br>SQMK96-3636<br>CCSK96-3636             |
|  | SS-4236 Single Threshold<br>42" D x 36" W             | SK-364872<br>STMK72-3662<br>SQMK72-3662<br>CCSK72-3648             | SK-364896<br>STMK96-3662<br>SQMK96-3662<br>CCSK96-3648             |
|  | SS-4242 Single Threshold<br>42" D x 42" W             | SK-484896<br>SSST-6296-1<br>SSSQ-6296-1<br>SS-4896-1               | SK-484896<br>SSST-6296-1<br>SSSQ-6296-1<br>SS-4896-1               |
|  | SS-DTF Double Threshold DTF<br>36" D x 36" W          | SS-3672-2<br>SSST-3696-1<br>SSSQ-3696-1<br>CCSP-3672-1             | SS-3696-2<br>SSST-3696-1<br>SSSQ-3696-1<br>CCSP-3696-1             |

Choose only wall panels directly to the right of your shower pan.









*Note: Actual shower dimensions may vary, some trimming of panels may be required.*

### Shower Wall Selection (continued)

#### 1 Find your shower pan size.

Choose from the list below. Then follow the chart across to find the elements that are right for your custom Swanstone shower. See below for information about Shower Kits.

#### 2 Choose your shower wall panel height.

|   |   | 72" high wall panels | 96" high wall panels |
|---|---|----------------------|----------------------|
|    | SS-36NEO Neo Angle<br>36" D x 36" W   | SS-3672-2            | SS-3696-2            |
|   |   | SSST-3696-1          | SSST-3696-1          |
|   |   | SSSQ-3696-1          | SSSQ-3696-1          |
|   |   | CCSP-3672-1          | CCSP-3672-1          |
|    | SS-38NEO Neo Angle<br>38" D x 38" W   | SK-4896-2            | SK-4896-2            |
|   |   | SSST-6296-1          | SSST-6296-1          |
|   |   | SSSQ-6296-1          | SSSQ-6296-1          |
|    | BF-3060L/R Barrier Free <br>30" D x 60" W      | SK-366072            | SK-366296            |
|   |   | STMK72-3662          | STMK96-3662          |
|   |   | SQMK72-3662          | SQMK96-3662          |
|    | SBF-3462 Barrier Free <br>34" D x 62" W        | SK-366272            | SK-366272            |
|   |   | STMK72-3662          | STMK96-3662          |
|   |   | SQMK72-3662          | SQMK96-3662          |
|  | STS-3838 Transfer Shower Pan <br>38" D x 38" W | SK-364872            | SK-364896            |
|   |   | CCSK72-3648          | SK-484896            |
|   |   |                      | CCSK96-3648          |

Choose only wall panels directly to the right of your shower pan.

Note: Actual shower dimensions may vary, some trimming of panels may be required.

| SK Kits           | STMK/SQMK Kits    | CCSK Kits              |
|-------------------|-------------------|------------------------|
| Wall Panels       | Wall Panels       | Wall Panels            |
| ES-2 Soap Shelves | ES-2 Soap Shelves | CCSS-1125 Soap Shelves |
| Silicone          | Silicone          | Silicone               |
| Corner Moldings   |                   |                        |

| Height | Width | 1 Panels   | 2 Panels                   |                |
|--------|-------|--|----------------------------|----------------|
| 72"    | 36"   | SS-3672-1<br>CCSP-3672-1                               | SS-3672-2<br>-             |                |
|        | 60"   | SS-6072-1  | -                          |                |
| 96"    | 36"   | SS-3696-1<br>SSST-3696-1<br>SSSQ-3696-1<br>CCSP-3696-1 | SS-3696-2<br>-<br>-<br>-   |                |
|        |       | 48"  | SS-4896-1<br>CCSP-4896-1   | SS-4896-2<br>- |
|        |       |  | SS-6296-1                  | -              |
|        |       | 62"  | SSST-6296-1<br>SSSQ-6296-1 | -<br>-         |

Note: Installation kits must be ordered separately when installing individual panels

#### 3 Choose optional Trim Kit/ Corner Molding

| 72" High Walls                                | 96" High Walls                               |
|---|--|
| TK-6072 includes edge trim and corner molding | TK-105 includes edge trim and corner molding |
| CM-2072 only includes corner molding          | CM-2096 only includes corner molding         |

Note: Trim Kits and corner molding are not offered for the Crystal Colors "CCSKxxxx" models.

#### 4 Finish your custom shower by selecting from the Accessory Selection section on the next page.